

PO Box 180 Rosewood, Qld 4340 Australia www.KenLowe.com.au
Phone 0411-699 535

Access Door Assembly

Door Opening Size 5" x 6" Outside Frame Size 7" x 8"

With Non Wing Latch (shown)

PN 58218-73500

With Butterfly Wing Latch

PN 58218-73501









Cut your panel out and rivet in place and you have an access door. We can install it for you and give you a recessed installation with our special tool.