

## Idle Bleed Kit

If your barrel valve is set for the correct amount of fuel delivery to the engine at idle and you want to change the idle speed if you adjust the butterfly adjustment screws it also moves the barrel




valve changing the fuel delivery at idle. Putting an "Idle Bleed Kit" in the hat below or after the butterflies allows you to adjust the air to the engine without having to adjust the butterflies. Usually three "Idle Bleed Kits" are all that is necessary to give you a full range of adjustment in air delivery at idle.

With our kit you have three adjustments.

One is with the plug in and you have no air going through the bleed.

The second is with the bit of hose letting some air in.



The third adjustment is with the plug and hose both out

allowing max flow through this particular air bleed fitting. Can be used on both normally aspirated and supercharged engines.

## One Kit includes

- 1ea push lock fitting
- 1ea push lock plug
- 1ea 6mm hose

**PN 35350-00000 ..... L\$ 16.50+      RDD \$14.50+**